100 KHz to 3 GHz, 2 probes

3 AXIS RADIO FREQUENCY

ELECTROMAGNETIC FIELD METER

Model: EMF-839 *ISO-9001, CE, IEC1010*





The Art of Measurement

3 AXIS RF ELECTROMAGNETIC FIELD METER

Model: EMF-839

FEATURES

TEATORES	
* 3 Axis probe.	
* Wide measuring frequency ranges, 100 KHz to 3 GHz.	
* Radio frequency electromagnetic field tester.	
* EMF-839 is used for broadband devices of monitoring	
the wide range radio frequency electromagnetic field	
value.	
* For precision measurement consideration, the meter	
are included two probes :	
EP-04L (Low frequency Probe, 100 KHz to 100 MHz)	
EP-03H (High frequency Probe, 100 MHz to 3 GHz)	
* Unit : V/m, W/m^2, mW/cm^2.	
* Alarm setting function can warn the user if the	
measuring antenna is too near the strong radiation	
sources, the buzzer will sound to remind the user.	
* Peak hold function to latch peak value.	
* Data hold function to lock the current reading.	
* RS232 computer interface.	
* Real time data logger, build in clock (hour-MIN-sec.,	
year-month-date).	
* Auto or manual data record, 16,000 Data logger no.	
* Wide sampling time adjustment range from one second	
to 8 hours 59 minutes 59 seconds.	
* Compact metallic carry case.	
* Large size LCD with contrast adjustment, which can fit	
best viewing angle.	
* Microcomputer circuit provides special function & offers	
high accuracy.	

APPLICATIONS

This meter is specially developed for measuring or monitoring electromagnetic field, for example: cell-phone station, hospital equipment, radar, micro-wave oven, radiation work, TV antenna, Radio station, welding equipment, baking-equipment, television, computer, factory, laboratory, and other environment...etc

* Powered by 006P DC 9V battery or DC 9V adapter.

SAFETY INSTRUCTIONS

Danger

- For worker's safety, be aware that persons with electromagnetic implant (e.g. cardiac-pacemarker) are subject to especial danger in some case.

 Particular to observe the local safety regulations of the
- operator of the equipment.
- Before using the device, it need to know that how to setting " alarm-limit " value.

Attention

- Claims by some scientists that long term exposure to electromagnetic field may be the cause of childhood leukemia & other forms of cancer.
- Complete answers to any of these and related questions are not currently available. At the present time the most common practice is to avoid excess exposure over long period of time.
- Complete answers to any of these and related " Prudent Avoidance " as stated by the Environmental Protection Agency(EPA) USA is recommended.
- According to ICNIRP of reference levels to time-varying electromagnetic fields, The E-field strength levels are:

General public

Contra public			
Frequency range	e-field strength (V/m)		
3 to 150 kHz	87		
0.15 to 1 MHz	87		
1 to 10 MHz	87/f^1/2		
10 to 400 MHz	28		
400 to 2000 MHz	1.375 x f^1/2		
2 to 300 GHz	61		

Occupational

Frequency range	e-field strength (V/m)
65 to 1000 kHz	610
1 to 10 MHz	610/f
10 to 400 MHz	61
400 to 2000 MHz	3 x f^1/2
2 to 300 GHz	137

GENERAL SPECIFICATIONS

GENERAL SPECI				
Circuit	Custom one-chip of microprocessor LSI circuit.			
Display	LCD size: 58 mm x 34 mm.			
Measurement	V/m, mW/cm^2, W/m^2.			
Unit				
Accuracy	< 2 dB.			
Probe structure	3 Axis.			
Probe Type	EP-03H: 100 MHz to 3 GHz.			
Selection	EP-04L: 100 kHz to 100 MHz.			
Probe Input	50 OHM			
Impedance				
Frequency	EP-03H: 900 MHz, 1 GHz, 1.8 GHz,			
Selection	2.4 GHz, 2.45 GHz, 3 GHz.			
Points	EP-04L: 100kHz, 200kHz, 500kHz, 1MHz, 10MHz, 13.56MHz, 100MHz.			
Sensor	Semiconductor			
Structure				
Sampling Time	Manual	Press the data logger button		
of Data Logger	marraar	once will save data one time.		
		* Set the sampling time to		
		0 second		
	Auto	1 sec to 8 hour 59 min. 59 sec.		
Data Hold		e display reading.		
REC Function	Record N	laximum & Minimum value.		
Power off	Auto shu	t off saves battery life or		
		off by push button.		
	* Can default auto power off or manual			
	power			
	* When	default auto power off ,		
		will off automatically after		
A		if no button be pressed.		
Peak Hold	To latch	the peak measurement value.		
Peak Hold Alarm Setting		the peak measurement value. ill sound when display over the		
		ill sound when display over the		
	Buzzer w setting va Approx.	ill sound when display over the alue.		
Alarm Setting	Buzzer w setting va Approx. 1	ill sound when display over the alue. I second. play show Low battery		
Alarm Setting Sampling Time	Buzzer w setting va Approx. 1	ill sound when display over the alue.		
Alarm Setting Sampling Time Low Battery Indicator Data Output	Buzzer w setting va Approx. ' When dis Indicator RS 232 P	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating	Buzzer w setting va Approx. ' When dis Indicator	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature	Buzzer w setting va Approx. When dis Indicator RS 232 P 0 to 50 °(ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating	Buzzer w setting va Approx. When dis Indicator RS 232 P 0 to 50 °(ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity	Buzzer w setting va Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar	ill sound when display over the alue. I second. I second second second second second. I second secon		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating	Buzzer w setting va Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. 1 80 %RH. attery (006P)		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity	Buzzer w setting va Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy	ill sound when display over the alue. I second. play show Low battery it should change the batteries. C serial interface. 1 80 %RH. attery (006P) duty or Alkaline type.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply	Buzzer w setting va Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. 1 80 %RH. attery (006P) duty or Alkaline type. lapter input.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current	Buzzer w setting va Approx. ' When dis Indicator RS 232 P 0 to 50 °(Less thar DC 9 V b * Heavy DC 9V ac Approx. I	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. C. in 80 %RH. lattery (006P) duty or Alkaline type. lapter input. DC 5.95 mA		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight	Buzzer w setting vs Approx. Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b + Heavy DC 9V a Approx. E 523 g/ 1	ill sound when display over the alue. 1 second. I second. I play show Low battery I it should change the batteries. C serial interface. C. 1 80 %RH. 1 attery (006P) 1 duty or Alkaline type. 1 lapter input. 1 C 5.95 mA 1.16 LB.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current	Buzzer w setting va Approx. ' When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac Approx. I 523 g/ 1	ill sound when display over the alue. I second. Iplay show Low battery I, it should change the batteries. C serial interface. In 80 %RH. Battery (006P) If alue of alkaline type. Bapter input. In 6 LB. Battery (Language of the batteries of the batte		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight	Buzzer w setting va Approx. ' When dis Indicator RS 232 P 0 to 50 '(Less thar DC 9 V b * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst	ill sound when display over the alue. 1 second. I second. I play show Low battery I it should change the batteries. C serial interface. C. 1 80 %RH. 1 attery (006P) 1 duty or Alkaline type. 1 lapter input. 1 C 5.95 mA 1.16 LB.		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight	Buzzer w setting va Approx. 2 When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0; Probe:	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. I 80 %RH. attery (006P) aduty or Alkaline type. lapter input. 0.0 5.95 mA .16 LB. frument: k 76.2 x 36.8 mm		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension	Buzzer w setting va Approx. 2 When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0: 2 70 mm	ill sound when display over the alue. I second. play show Low battery it should change the batteries. C serial interface. a 80 %RH. attery (006P) aduty or Alkaline type. lapter input. DC 5.95 mA .16 LB. frument: x 76.2 x 36.8 mm		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories	Buzzer w setting va Approx. Approx. When dis Indicator RS 232 P 0 to 50 °C Less than DC 9 V b. * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0: 70 mm Instruction	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. D 80 %RH. attery (006P) duty or Alkaline type. lapter input. DC 5.95 mA .16 LB. drument: x 76.2 x 36.8 mm I (diameter) x 290 mm (length) on manual		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension	Buzzer w setting vs Approx. Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0; Probe: 70 mm Instructic EP-03H F	ill sound when display over the alue. I second. I second. I play show Low battery I it should change the batteries. C serial interface. I 80 %RH. I attery (006P) I duty or Alkaline type. I alapter input. DC 5.95 mA I 6 LB. I wment: I 76.2 x 36.8 mm I (diameter) x 290 mm (length) I m manual		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories	Buzzer w setting va Approx. 'Approx. 'When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DG 9 V ac Approx. 'Business 1	ill sound when display over the alue. I second. Iplay show Low battery I, it should change the batteries. C serial interface. In 80 %RH. In 80 %		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories	Buzzer w setting va Approx. ' When dis Indicator RS 232 P 0 to 50 '(Less thar DC 9 V b * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0 : Probe : 70 mm Instruction EP-03H P EP-04L P Memory v	ill sound when display over the alue. I second. Iplay show Low battery I, it should change the batteries. C serial interface. In 80 %RH. Set of the series of the se		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories	Buzzer w setting va Approx. Approx. When dis Indicator RS 232 P O to 50 C Less than DC 9 V b. Heavy DC 9V ac Approx. It 523 g/ 1 Main inst 200.0 Probe: 70 mm Instructic EP-03H P EP-04L P Memory w Memory of Approx of the setting of	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. In 80 %RH. attery (006P) duty or Alkaline type. lapter input. DC 5.95 mA .16 LB. rument: x 76.2 x 36.8 mm I (diameter) x 290 mm (length) on manual		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories	Buzzer w setting va Approx. 2 When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0; Probe: 70 mm Instructic EP-03H P EP-04L P Memory v DC 9V pc	ill sound when display over the alue. I second. play show Low battery , it should change the batteries. C serial interface. In 80 %RH. attery (006P)		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories Included	Buzzer w setting vs Approx. Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b + Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0; Probe: 70 mm Instructic EP-03H P EP-04L P Memory Memory Memory of DC 9V pc Metal car	ill sound when display over the alue. I second. I second. I play show Low battery I it should change the batteries. C serial interface. C serial interface. I 80 %RH. I attery (006P) I duty or Alkaline type. I apter input. I C 5.95 mA I 6 LB. I rument: I (diameter) x 290 mm (length) I manual		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories Included	Buzzer w setting vs Approx. Approx. When dis Indicator RS 232 P 0 to 50 °C Less thar DC 9 V b. Heavy DC 9V ac Approx. I 523 g/ 1 Main inst 200.0: Probe: 70 mm Instructic EP-03H P EP-04L P Memory w Memory w DC 9V pc Metal car RS232 ca	ill sound when display over the alue. I second. I second. I play show Low battery I it should change the batteries. C serial interface. I 80 %RH. I attery (006P) I duty or Alkaline type. I lapter input. DC 5.95 mA .16 LB. I wiment: I (diameter) x 290 mm (length) I manual		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories Included	Buzzer w setting va Approx. ' Approx. ' When dis Indicator RS 232 P O to 50 °C Less thar DC 9 V b. * Heavy DC 9V ac Approx. E 523 g/ 1 Main inst 200.0: Probe: ' 70 mm Instruction EP-04L P Memory (Memory (Memory (Memory (Memory (Metal car RS232 ca USB cable)	ill sound when display over the alue. I second. I second. Iplay show Low battery I, it should change the batteries. C serial interface. I 80 %RH. I attery (006P) I duty or Alkaline type. I alapter input. I C 5.95 mA I 6 LB. I wment: I 76.2 x 36.8 mm I (diameter) x 290 mm (length) I pc		
Alarm Setting Sampling Time Low Battery Indicator Data Output Operating Temperature Operating Humidity Power Supply Power Current Weight Dimension Accessories Included	Buzzer w setting va Approx. Approx. Setting va Appr	ill sound when display over the alue. I second. I second. I play show Low battery I it should change the batteries. C serial interface. I 80 %RH. I attery (006P) I duty or Alkaline type. I lapter input. DC 5.95 mA .16 LB. I wiment: I (diameter) x 290 mm (length) I manual		

ELECTRICAL SPECIFICATIONS (23 ± 5 °C)

Strength Range	Resolution		Effective Value		
0~200.00 V/m	0.01 V/m		> 1 V/m		
0~99.999 W/m^2	0.001 W/m^2		> 0.03 W/m^2		
0~9.9999 mW/cm^2	0.0001 mW/cm^2		> 0.0003 mW/cm^2		
	•		•		
Frequency range	Accuracy	Cal.	level	Probe no.	
*100 KHz to 100 MHz	< 2 dB	30 V	/m	EP-04L	

Remark:

- * EP-04L probe's accuracy is specified within 400 KHz to 100 MHz only. If measurement frequency range is < 400 KHz, the reading value just for reference only.
- EP-03H probe's accuracy is specified within 100 MHz to 2.5 GHz only. If measurement frequency range $\,$ is < 100 MHz or > 2.5 GHz, the reading value just for reference only.
- * For precision measurement consideration, it should select the " Frequency Team point " near the frequency value of measuring object.

Appearance and specifications listed in this brochure are subject to change without notice

NCC (National Communication Commission is the official organization on behalf Taiwan government)

NCC RECOMMEND EMF-839, EMF-819 for Mobile station measurement



NCC Website: http://www.ncc.gov.tw